



HOT IN START OR RUN

FUSE PANEL

SEE POWER DISTRIBUTION




IGNITION SYSTEM


WITH ELECTRIC SHIFT

WITHOUT ELECTRIC SHIFT

ELECTRIC SHIFT ONLY



ELECTRIC SHIFT CONTROL



REAR ANTI-LOCK BRAKE SYSTEM

4X4 INDICATOR SWITCH