


\* PULSING WITH TURN OR HAZARD SWITCH CLOSED

Turning the Ignition Switch from RUN to OFF and opening the driver's door will cause the RAP Module to flash the "Anti-Theft" Indicator. After locking the doors, the indicator will stay on for approximately 30 seconds then go off, indicating that the system is armed.



Indicator will light when the turn signal lever is put in the right or left turn position.

Indicator will light when the Dimmer/Flash to Pass Switch is put into High beam position.

GROUNDS

INSTRUMENT CLUSTER